

Table 4.1. Use Case Index Table

Project Name: Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform				
Use Case ID	Use Case Name	Level	Author	Version
UC-001	Start Monitoring Session	Summary	Chase Tanner	0.1
UC-002	Detect and Alert Driver Drowsiness	Summary	Tarig Elamin	0.1
UC-003	Acknowledge or Snooze Alert	Summary	Tarig Elamin	0.1
UC-004	Adjust Sensitivity and Settings	Summary	Tarig Elamin	0.1
UC-005	Calibrate / Align Camera	Summary	Tarig Elamin	0.1
UC-006	View Alert Summary	Summary	Tarig Elamin	0.1
UC-007	Export Logs	Primary task	Tarig Elamin	0.1
UC-008	Manage App Deployment (System Administrator)	Subfunction	Tarig Elamin	0.1
UC-009	View Aggregated Reports (Fleet Manager)	Summary	Tarig Elamin	0.1
UC-010	Receive Distraction Alert	Summary	Tarig Elamin	0.1
Acknowledgment: Generated from the CapStone process management system ©2025				

Table 4.2. Use Case UC-001

<b>Project Name:</b>	<b>Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform</b>
<b>Use Case ID:</b>	UC-001
<b>Use Case Name:</b>	Start Monitoring Session
<b>User Goal:</b>	The driver wants to manually start and stop monitoring a session so they can control when the app analyzes their driving behavior
<b>Scope:</b>	Driver Monitoring Sub-System
<b>Level:</b>	Summary
<b>Relevant User Reqs:</b>	UF-B,UF-E,UF-H
<b>Relevant System Reqs:</b>	SF-B-01,SF-B-02,SF-C-01
<b>Primary Actor:</b>	Driver (mobile app user)
<b>Precondition:</b>	The ALVION app is installed and permissions (camera, audio, vibration) are granted. User is logged in
<b>Minimal Guarantee:</b>	If camera permission is denied or initialization fails, the app informs the user and remains idle
<b>Success Guarantee:</b>	Monitoring session begins successfully; live interface runs at $\geq 15$ FPS, analyzing eye openness and head orientation.
<b>Trigger:</b>	Driver taps "Start Monitoring" on main dashboard screen
<b>Success Scenario:</b>	<b>Step    Actions</b>
	<b>1</b> The user launches the ALVION application
	<b>2</b> The system request camera, audio, and vibration permissions if not already granted
	<b>3</b> The user taps "Start Monitoring"
	<b>4</b> The system activates the front-facing camera via CameraX
	<b>5</b> The system initializes the on-device ML inference engine using Snapdragon CPU/GPU/NPU
	<b>6</b> The system calibrates the frame to ensure lighting and positioning are valid
	<b>7</b> The system begins continuous real-time analysis of eye openness and head orientation
	<b>8</b> The system triggers an alert if drowsiness or distraction is detected
	<b>9</b> The user can manually tap "Stop Monitoring" to end the session
	<b>10</b> The system records the session timestams and saves the results locally
<b>Extensions:</b>	<b>Branching Scenarios</b>
<b>3A</b>	<b>Condition:</b> Camera permission denied
	<b>Step    Actions</b>
	<b>1</b> The system displays error "Camera access is required to begin monitoring". Disable Start button until granted
<b>3B</b>	<b>Condition:</b> Calibration fails (low lighting)

	<b>Step</b>	<b>Actions</b>
	1	The system Prompt user "Lighting insufficient -- please adjust position or brightness".
3C	<b>Condition:</b> Hardware overload (temperature threshold exceeded)	
	<b>Step</b>	<b>Actions</b>
	1	The system notifies driver "Monitoring paused to cool device".
3D	<b>Condition:</b> User revokes permission during session	
	<b>Step</b>	<b>Actions</b>
	1	The system suspends monitoring safely and informs the driver
<i>Acknowledgment: Generated from the CapStone process management system ©2025</i>		

Table 4.3. Use Case UC-002

<b>Project Name:</b>	<b>Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform</b>
<b>Use Case ID:</b>	UC-002
<b>Use Case Name:</b>	Detect and Alert Driver Drowsiness
<b>User Goal:</b>	The driver wants the system to monitor their face and eyes in real time and warn them immediately if signs of drowsiness are detected, helping them stay alert and safe.
<b>Scope:</b>	Distracted/Drowsy Driver Detection System (the in-
<b>Level:</b>	Summary
<b>Relevant User Reqs:</b>	UF-B
<b>Relevant System Reqs:</b>	SF-B-01,SF-B-02
<b>Primary Actor:</b>	Driver
<b>Precondition:</b>	1- The system is installed and running. 2- The camera is calibrated, and lighting conditions allow detection. 3- Driver monitoring mode is active.
<b>Minimal Guarantee:</b>	If sensors fail or detection confidence is too low, the system logs the issue and notifies the driver that monitoring accuracy is reduced
<b>Success Guarantee:</b>	If drowsiness is detected, the system immediately issues audible and visual alerts, prompting the driver to regain focus
<b>Trigger:</b>	The system detects drowsiness indicators (e.g., eyes closed for prolonged periods or slow blink rate)
<b>Success Scenario:</b>	<b>Step    Actions</b>
	<b>1</b> The system continuously monitors the driver's eyes and facial expressions using the camera.
	<b>2</b> The system analyzes blink frequency, eyelid closure duration, and gaze direction in real time.
	<b>3</b> The system the system classifies the state as "drowsy."
	<b>4</b> The system the system triggers audible and visual alerts
	<b>5</b> The user hears/see the alert and adjusts posture, eye focus, or takes a break.
	<b>6</b> The system monitoring continues once the driver's state normalizes.
<b>Extensions:</b>	<b>Branching Scenarios</b>
<b>1A</b>	<b>Condition:</b> The Driver continues to show "drowsy" symptoms for a long pried of time
	<b>Step    Actions</b>
	<b>1</b> The system sends notification to family members and emergency contacts
<i>Acknowledgment: Generated from the CapStone process management system ©2025</i>	

Table 4.4. Use Case UC-003

Project Name:	Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform
Use Case ID:	UC-003
Use Case Name:	Acknowledge or Snooze Alert
User Goal:	The driver acknowledges an alert or snoozes further alerts for a short cooldown.
Scope:	Driver Monitoring Sub-System
Level:	Summary
Relevant User Reqs:	UF-D,UF-F,UF-G,UF-I,UF-J
Relevant System Reqs:	SF-A-01,SF-B-01,SF-D-01
Primary Actor:	Driver
Precondition:	A drowsiness or distraction alert has just been displayed.
Minimal Guarantee:	If input is not received, alert auto-dismisses after timeout; monitoring continues.
Success Guarantee:	System records the user action and applies cooldown if snoozed.
Trigger:	Driver taps "Acknowledge" or "Snooze".
Success Scenario:	<div>StepActions</div>
	<div>1The system presents actions: Acknowledge   Snooze.</div>
	<div>2The Driver selects an action.</div>
Extensions:	Branching Scenarios
1A	Condition: If Acknowledge
	<div>StepActions</div>
	<div>1The system System clears alert UI and logs acknowledgment.</div>
	<div>2The system updates session stats.</div>
1B	Condition: If Snooze
	<div>StepActions</div>
	<div>1System starts cooldown timer; suppresses new alerts.</div>
	<div>2The system updates session stats.</div>
Acknowledgment: Generated from the CapStone process management system ©2025	

Table 4.5. Use Case UC-004

<b>Project Name:</b>	<b>Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform</b>
<b>Use Case ID:</b>	UC-004
<b>Use Case Name:</b>	Adjust Sensitivity and Settings
<b>User Goal:</b>	The driver adjusts thresholds (eye-closure time, yaw angle) and alert cooldown/volume; changes persist locally between sessions.
<b>Scope:</b>	Settings Sub-System
<b>Level:</b>	Summary
<b>Relevant User Reqs:</b>	UF-D
<b>Relevant System Reqs:</b>	SF-D-01,SF-D-02,SF-D-03
<b>Primary Actor:</b>	Driver
<b>Precondition:</b>	App is installed; monitoring may be idle or running.
<b>Minimal Guarantee:</b>	Invalid inputs are rejected with guidance; previous values remain.
<b>Success Guarantee:</b>	New settings are validated, saved, and hot-applied to active monitoring.
<b>Trigger:</b>	Driver opens Settings.
<b>Success Scenario:</b>	<b>Step    Actions</b>
	<b>1</b> The user navigates to Settings.
	<b>2</b> The system loads current Settings (thresholds, cooldown, volume) and displays controls.
	<b>3</b> The user edits one or more values (e.g., PERCLOS window, yaw threshold, alert volume/cooldown).
	<b>4</b> The system validates ranges and dependencies.
	<b>5</b> The system persists updates locally and, if monitoring is active, hot-applies them to detection/alerts.
	<b>6</b> The system confirms "Settings saved."
<b>Extensions:</b>	<b>Branching Scenarios</b>
<b>3A</b>	<b>Condition:</b> Out-of-range value
	<b>Step    Actions</b>
	<b>1</b> The system clamps or shows inline error; cannot save until valid.
<b>5A</b>	<b>Condition:</b> Restore defaults
	<b>Step    Actions</b>
	<b>1</b> The user taps Restore; system resets to defaults and saves.
<b>Acknowledgment: Generated from the CapStone process management system ©2025</b>	

Table 4.6. Use Case UC-005

<b>Project Name:</b>	<b>Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform</b>
<b>Use Case ID:</b>	UC-005
<b>Use Case Name:</b>	Calibrate / Align Camera
<b>User Goal:</b>	Align the camera/phone so the face is centered and lighting is sufficient before monitoring.
<b>Scope:</b>	Calibration Sub-System
<b>Level:</b>	Summary
<b>Relevant User Reqs:</b>	UF-H
<b>Relevant System Reqs:</b>	SF-H-01,SF-H-02
<b>Primary Actor:</b>	Driver
<b>Precondition:</b>	Camera permission granted; preview available.
<b>Minimal Guarantee:</b>	If calibration fails, user receives guidance and can retry or skip.
<b>Success Guarantee:</b>	Calibration passes; app allows monitoring to start (or continues with improved alignment).
<b>Trigger:</b>	First use, or system detects poor alignment/lighting; driver taps Start Calibration.
<b>Success Scenario:</b>	<b>Step    Actions</b>
	<b>1</b> System shows live preview with guidance overlays (face box/eye markers).
	<b>2</b> System evaluates framing stability and pose (e.g., yaw/pitch within bounds) and lighting quality.
	<b>3</b> When all criteria hold for the window, system marks Calibration Passed.
	<b>4</b> System returns to main screen with Start Monitoring enabled (or auto-continues if already starting).
<b>Extensions:</b>	<b>Branching Scenarios</b>
<b>1A</b>	<b>Condition:</b> User skips
	<b>Step    Actions</b>
	<b>1</b> The system Start remains allowed but with degraded confidence notice until conditions improve
<b>2A</b>	<b>Condition:</b> Insufficient lighting/unstable face
	<b>Step    Actions</b>
	<b>1</b> Show tips (increase brightness, hold steady, reposition); remain in calibration.
<i>Acknowledgment: Generated from the CapStone process management system ©2025</i>	

Table 4.7. Use Case UC-006

Project Name:	Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform
Use Case ID:	UC-006
Use Case Name:	View Alert Summary
User Goal:	After a session, the driver reviews counts by alert type, timeline, duration, and average PERCLOS.
Scope:	Reporting (Local)
Level:	Summary
Relevant User Reqs:	UF-I
Relevant System Reqs:	SF-I-01,SF-I-02
Primary Actor:	
Precondition:	At least one session ended with recorded events.
Minimal Guarantee:	If no events exist, show “No alerts recorded” with session duration.
Success Guarantee:	Summary displays key metrics from local storage and supports time-range filters.
Trigger:	Driver taps Summary.
Success Scenario:	<b>Step    Actions</b>
	1     Driver selects Last Session, Today, 7 Days, or Custom.
	2     The system loads session data locally and aggregates counts, durations, and PERCLOS.
	3     The system renders timeline and KPI cards.
	4     The user closes summary or proceeds to Export.
Extensions:	Branching Scenarios
2A	<b>Condition:</b> Data missing/corrupted
	<b>Step    Actions</b>
	1     The system shows error and offers diagnostics/logs link.
Acknowledgment: Generated from the CapStone process management system ©2025	



Table 4.8. Use Case UC-007

Project Name:	Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform		
Use Case ID:	UC-007		
Use Case Name:	Export Logs		
User Goal:	Export anonymized summaries (and optional event logs) for external analysis—offline and consented.		
Scope:	Reporting (Local Export)		
Level:	Primary task		
Relevant User Reqs:	UF-I,UF-J		
Relevant System Reqs:	SF-J-03		
Primary Actor:	Driver		
Precondition:	Local session data exists; user consents to export.		
Minimal Guarantee:	If storage permission denied or canceled, no file is written.		
Success Guarantee:	A CSV/JSON file is created with aggregated/session fields—no PII or images.		
Trigger:	Driver taps Export from Summary or Settings.		
Success Scenario:	Step    Actions		
	1	The system presents consent text and lets the user choose CSV or JSON and a destination.	
	2	The system serializes summaries (and optional event rows) and writes to selected location.	
	3	The system confirms success and offers Open	
Extensions:	Branching Scenarios		
1A	Condition: User cancels/denies permission		
	Step    Actions		
	1	The system Abort export; show guidance.	
Acknowledgment: Generated from the CapStone process management system ©2025			

Table 4.9. Use Case UC-008

<b>Project Name:</b>	<b>Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform</b>
<b>Use Case ID:</b>	UC-008
<b>Use Case Name:</b>	Manage App Deployment (System Administrator)
<b>User Goal:</b>	Deploy updates, enforce permissions, and apply managed configurations uniformly across devices.
<b>Scope:</b>	Device Management / Deployment
<b>Level:</b>	Subfunction
<b>Relevant User Reqs:</b>	UF-K
<b>Relevant System Reqs:</b>	SF-K-01,SF-K-02
<b>Primary Actor:</b>	System Administrator
<b>Precondition:</b>	Devices are enrolled in enterprise MDM; app is approved in store.
<b>Minimal Guarantee:</b>	If a policy cannot be applied, admin is notified with reason.
<b>Success Guarantee:</b>	Target devices receive the assigned version and enforced settings; status is auditable.
<b>Trigger:</b>	Admin schedules a rollout or pushes a policy refresh
<b>Success Scenario:</b>	<b>Step    Actions</b>
	<b>1</b> Admin selects device group(s) and rollout plan (staged or immediate).
	<b>2</b> MDM distributes the app/update and managed configs (permissions, locked settings).
	<b>3</b> Devices install/update and apply configs automatically.
	<b>4</b> App reflects managed settings and displays “Managed by your organization.”
	<b>5</b> Admin reviews deployment status and audit logs in the console.
<b>Extensions:</b>	<b>Branching Scenarios</b>
<b>2A</b>	<b>Condition:</b> Policy revokes CAMERA
	<b>Step    Actions</b>
	<b>1</b> App transitions to IDLE, releases camera, shows policy notice.
<b>3A</b>	<b>Condition:</b> Device offline
	<b>Step    Actions</b>
	<b>1</b> MDM queues install; applies on next check-in.
<i>Acknowledgment: Generated from the CapStone process management system ©2025</i>	

Table 4.10. Use Case UC-009

Project Name:	Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform		
Use Case ID:	UC-009		
Use Case Name:	View Aggregated Reports (Fleet Manager)		
User Goal:	View aggregated drowsiness/distraction trends across drivers to identify safety issues and inform policies.		
Scope:	Fleet Reporting (Future)		
Level:	Summary		
Relevant User Reqs:	UF-L		
Relevant System Reqs:	SF-L-01,SF-L-02,SF-L-03		
Primary Actor:	Fleet Manager		
Precondition:	Consented, anonymized summaries have been uploaded to an org data store.		
Minimal Guarantee:	If data for a range is missing, dashboard shows “incomplete coverage.”		
Success Guarantee:	Dashboard shows alerts/hour, type distribution, and time-of-day/week trends with filters and export.		
Trigger:	Manager opens Fleet Dashboard and selects filters and date range.		
Success Scenario:	Step    Actions		
	1	The system aggregates data for the selected org/cohort/date range, normalized by monitored hours.	
	2	The system renders trend charts and KPIs (alerts/hr, type mix, peak hours).	
	3	The user exports CSV/PDF for sharing.	
Extensions:	Branching Scenarios		
1A	Condition: Small cohort (<5 drivers)		
	Step    Actions		
	1	The system Suppress display to protect privacy (k-anonymity).	
2A	Condition: Backend unavailable		
	Step    Actions		
	1	Serve last-known aggregates with a stale badge.	
Acknowledgment: Generated from the CapStone process management system ©2025			

Table 4.11. Use Case UC-010

<b>Project Name:</b>	<b>Distracted/Drowsy Driver Detection on Snapdragon Mobile Platform</b>
<b>Use Case ID:</b>	UC-010
<b>Use Case Name:</b>	Receive Distraction Alert
<b>User Goal:</b>	The driver is alerted when their head remains turned away from the forward direction longer than the allowed threshold, so they can refocus attention.
<b>Scope:</b>	Driver Monitoring Sub-System
<b>Level:</b>	Summary
<b>Relevant User Reqs:</b>	UF-C
<b>Relevant System Reqs:</b>	SF-C-02,SF-F-02
<b>Primary Actor:</b>	Driver
<b>Precondition:</b>	Monitoring session is active; camera/inference running; thresholds configured. (See UC-001 preconditions for session start details.)
<b>Minimal Guarantee:</b>	If face/pose confidence is low, the system withholds the alert and logs the reason.
<b>Success Guarantee:</b>	A distraction alert (visual + configured audio/vibration) is issued and recorded with timestamp and metrics.
<b>Trigger:</b>	Head yaw remains beyond the configured threshold for longer than the dwell time.
<b>Success Scenario:</b>	<b>Step    Actions</b>
	<b>1</b> System continuously estimates head yaw from the face-detection model.
	<b>2</b> System accumulates time while  yaw  exceeds the threshold.
	<b>3</b> When dwell time is reached, system creates a DISTRACTED event (with yaw peak, duration, confidence).
	<b>4</b> The System issues a real-time alert (visual banner + audio/vibration per settings).
	<b>5</b> The System logs the event in the current session for later summary/reporting.
<b>Extensions:</b>	<b>Branching Scenarios</b>
<b>2A</b>	<b>Condition:</b> Low confidence / face not detected
	<b>Step    Actions</b>
	<b>1</b> The system pause dwell timer; show non-blocking tip (e.g., “reposition/brighten”); no alert.
<b>4A</b>	<b>Condition:</b> Alerts snoozed
	<b>Step    Actions</b>
	<b>1</b> The system suppress during cooldown; log suppression.
<i>Acknowledgment: Generated from the CapStone process management system ©2025</i>	